



# Instructions for use

## Use Only As Directed:

Digi Coat pre-treatment is a specially formulated compound that has a high affinity for glass and ceramic, which enables it to form robust physical bonds with such surfaces.

## Preparation Prior To Use:

Ensure all surfaces to be pre-treated are clean, and free from dirt or grease

## Directions for Use:

Digi Coat pre-treatment is applied to the substrate by means of a simple wipe on method using normal paper tissue or kitchen roll. Apply compound liberally, all over the surface to be coated, trying to ensure an even coverage. Allow the compound to bond with the surface for approximately 30 seconds, before removing any excess with clean tissue. When removing the excess, try to eliminate any greasy smudge marks (particularly relevant to glass surfaces).

## Safety:

Before storage or use please refer to manufacturers information. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice. Keep container tightly closed and in a well-ventilated place. Risk of serious damage to eyes, wear suitable gloves and eye/face protection.

Irritating to Skin.

