



# Instructions for use

## Use Only As Directed:

Digi Coat Translucent White Coating is a high quality multi-purpose sublimation coating for use on glass surfaces. Apply over Digi Coat clear sublimation coating allowing sublimation transfer to pass through. Use in conjunction with Digi Coat Clear.

## Preparation Prior To Use:

Shake Can Well for 1 minute.

Ensure the surface to be coated is clean dry and free from grease

## Directions for Use:

Prime surface with adhesion promoter.

Coat glass first with Digi Coat Clear (allow to air dry for 5 mins) then apply Translucent White over clear coating. Only a fine coat is required.

Spray at room temperature.

For best results spray product approx 250mm from surface using light passes.

Cure in oven at 160C for 15-20 mins.

Coverage approximately 2m<sup>2</sup>.

## Safety:

Pressurised container. Protect from sunlight and do not expose to temperatures exceeding 50°C. Do not pierce or burn even after use. do not spray onto a naked flame or any incandescent material.

Irritating to eyes. Repeated exposure may cause skin dryness or cracking. Vapours may cause drowsiness and dizziness. Keep out of reach of children. Keep away from sources of ignition - No smoking. Do not breathe vapour/spray. Avoid contact with eyes, rinse immediately with plenty of water and seek medical advice. Use only in well ventilated areas.

